

Option 2 requires the installer to cut off the excess ODS portion of the connector and then butt weld a pipe to the shortened connector. *Not available for 139A (2")