



Installation Instructions for All Oil Reservoirs

1. Locate the reservoir in a warm, draft-free area.
2. Install the reservoir in a vertical position between the separator and the oil level controls.
3. Clamp and support reservoir and piping properly to minimize vibration potential.
4. Be sure to not block view of oil sight glasses.
5. Install a pressure-reducing check valve from the oil reservoir vent port to suction line.
6. Keep reservoir cool when brazing.
7. Add the specific type of compressor oil being used, and fill to the bottom of the top sight glass.
8. Check oil level on new installations frequently.

For translations of these instructions, go to our website: [click here](#) or scan the QR code.



Questions? Call 1-800-552-9300 or 630.293.5910 or email us at temprite@temprite.com