



## 130, 920 and 920R Series Filter Access Clearance Chart

<b>Temprite Top Loading Separators: Clearance Height For Filter Accessibility</b>	
<b>Model</b>	<b>Minimum Overhead Clearance*</b>
133A, 922, 923, 922R, 923R	4" (102 mm)
135A, 924, 925, 924R, 925R	8" (203 mm)
137A, 926, 927, 926R, 927R	12" (305 mm)
928, 928R	16" (406 mm)
930, 930R	16" (406 mm)
139A	17" (432 mm)
138A	18" (457 mm)

\*Minimum overhead clearance is measured from top of separator top cover.

For translations of these instructions, go to our website: [click here](#) or scan the QR code.



**Questions? Call 1-800-552-9300 or 630.293.5910 or email us at [temprite@temprite.com](mailto:temprite@temprite.com)**